

1. Set 7898 Basin on your prepared, level, and stable site. Place pump in basin. Push power cord out bottom hole and pull from underneath, out of cord notch, toward your power supply. Open slit in stopper, place around power cord near pump, close, and press stopper into hole, leaving about 1/8" showing above the hole.

9. Fill all bowls and pool with water. Read pump instructions. Turn on the pump. If it does not immediately begin

working, there may be an "airlock" within the impeller chamber. Simply unplug and plug in a few times and it should start.

Csd 5/2020

START ...

## **Online Resources**

Products: www.henristudio.com/products
FAQs: www.henristudio.com/faq
Warranty: www.henristudio.com/warranty
Contact: www.henristudio.com/contact-us

Caution: The use of Chlorine or Chlorine Bleach or water coloring additives may damage the finish of your fountain.

## IMPORTANT – WINTER CARE

Winter ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:

- \* Disconnect power to pumps and lights.
- \* Remove plugs/stoppers in all fountain bowls to open drains and let all moisture out. Keep drains open throughout winter.
- \* Cover with a Henri fountain cover. Keep tight and do not let snow or water collect in sagging areas.
- \* Do not allow snow or ice to build up on or against the concrete. Remove snow before it turns to ice. Do not use antifreeze, salt or chemical ice removers as these may damage concrete.