


SET-UP INSTRUCTIONS FOR 2652F1

- 1) Prepare a suitable location for your new fountain. It should sit on a firm and level pad.
- 2) Always follow local electrical codes, making sure to connect to a safe GFCI circuit.
- 3) Set the 2652F1 concrete piece on your prepared setting.
- 4) From the front side, place the light below the waterfall area and insert the light power cord back through the hole at the bottom of the middle wall. Pull the cord out the fountain back and drape it over the back as shown.



- 5) Insert the 1/2\" male x 3/4\" barb adapter into the top of the pump.
- 6) Place the pump into the back reservoir face down (intake side down) with power cord out the back.
- 7) Attach the tube to the pump's barb fitting and to the barbed fitting which is preinstalled above the back reservoir (see drawing).
- 8) Insert the rectangular Foam Diffuser into the top of the waterfall, pressing down so it sits below the water line.
- 9) Fill the bowl unit with water to about 1\" from the top. Read your pump and light instructions. Then, plug in the pump and light to enjoy your fountain. If the pump does not immediately begin working, there may be an "airlock" within the impeller chamber. Simply unplug and plug in a few times and it should start.
- 10) Save this instruction and make sure to winterize according to details below.

csd

IMPORTANT – WINTER CARE

- Winter ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:
- * Disconnect power to pump.
 - * Remove plugs / stoppers in all fountain bowls to open drains and let all moisture out. Keep drains open throughout winter.
 - * Place an absorbant material like burlap, blankets, etc. inside vases/bowls and cover all with a Henri fountain cover.
 - * Do not allow snow or ice to build up on or against the concrete. Remove snow before it turns to ice. Do not use salt or chemical ice removers as these may damage concrete.