

# SETTING UP THE 4742F3 (and also the 4270F2, 5873F, and 9708F4)

- 1) Make sure to prepare a level and very firm area on which to set your new fountain in order to keep it from shifting due to settling soil.
- 2) Set the 7801 Base on the chosen spot. You may turn the pattern toward the more common viewing angle as you desire.
- 3) Set the 6801H Shell on the Base, facing the same angle. The bottom of the Shell has a matching flat area with the base, where the two should be positioned.
- 4) Insert the Exhaust fitting into the top of the pump and push the Tube onto the Exhaust. Slide the Restrictor onto the tube and tighten just enough for it to stay in place near the middle of the tube. Place the pump into the pump reservoir as shown and drape the power cord out the back of the shell using the slot provided in the back rim of the shell.
- 5) Set the Angel over the shell's pump reservoir. As you do, tip it and push the open end of the tube onto the pipe on the bottom of the Angel. Now set it down and position it to match the angle of the other pieces.
- 6) Read your pump instruction. Then fill the shell with water. Plug your pump into a GFCI protected circuit. If needed, you may reduce the power of the water flow by tightening the restrictor.
- 7) If your pump does not immediately pump water there may be an air lock ... air in the impeller chamber which blocks the water flow. Simply unplug and restart the pump a few times and this will clear.
- 8) Make sure to keep this instruction and follow the winter care tips (below) at the end of your warm weather season.

4/2019

## IMPORTANT – WINTER CARE

Winter ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:

- \* Disconnect power to pumps and lights.
- \* Remove plugs/stoppers in all fountain bowls to open drains and let all moisture out. Keep drains open throughout winter.
- \* Place an absorbant material like burlap or blankets inside vases/bowls - cover all with a Henri fountain cover.
- \* Do not allow snow or ice to build up on or against the concrete. Remove snow before it turns to ice. Do not use antifreeze, salt or chemical ice removers as these may damage concrete.

## Online Resources

Products: [www.henristudio.com/products](http://www.henristudio.com/products)  
Warranty: [www.henristudio.com/warranty](http://www.henristudio.com/warranty)

FAQs: [www.henristudio.com/faq](http://www.henristudio.com/faq)  
Contact : [www.henristudio.com/contact-us](http://www.henristudio.com/contact-us)

Make sure to place your fountain on a firm area which will not settle. Note: Always follow local electrical codes and use a 110V GFCI protected outlet.

**4742F3**

