


Roman Jar Fountain 5869F Assembly Instructions

- 1. Locate a suitable site for your Roman Jar Fountain. Site should be level and provide a pleasing viewing angle. You should always follow local electrical codes and use a GFCI Protected outlet.
- 2. Thread the standpipe into the 6869 Dish. Pass the power cord of the pump through the stand pipe leaving approximately 12-18" of cord to the inside of the Dish. The power cord should be routed under the Dish and out via of the notch. Install a rubber stopper over the power cord and insert it into the top of the stand pipe. The rubber stopper has a slit in it, Spread the stopper apart at the slit and slide the cord into the hole in the center of the stopper.
- 3. Connect the 36" X 1" NKT (No Kink Tubing) to the pump outlet with a hose clamp.
- 4. Place the 5869C Roman Jar Bottom over the standpipe and pump and pass the NKT up and over the top edge of the Jar. Level as necessary.
- 6. Place the 5869B Roman Jar Middle on the Jar Bottom and pass the NKT over the edge. Add a Flow Restrictor to the end of the NKT about 4-6" from the end.
- 7. Thread the Barb Adapter into the bottom of the 5869A Roman Jar Crown. Connect the NKT to the Barb Adapter and place the Jar Crown on the Jar Middle. Thread the small standpipe into the Jar Crown.
- 8. Add water to the Dish and start the pump when there is sufficient water to cover the pump. Adjust the water flow with the Flow Adjuster to obtain pleasing water action and flow over the rim of the Jar Crown.
- 9. We recommend that the final water level be approximately 1" below the top edge of the Dish.



5869F

IMPORTANT- WINTER CARE:

Do not allow water to collect and freeze in fountain bowl(s) or shell. Do not allow fountain pieces to sit in a pool of ice. Disassemble entire fountain and pump and store indoors during the winter season.

If you cannot store your fountain indoors during the winter season, you must at least protect if from ice collection or exposure. Protect your fountain during the winter season: first remove the statue(s) and pump, storing them inside if possible. Next, locate the drain plug on the underside of bowl(s) or shell. Remove drain plug to drain any water "trapped" between the walls of the bowl(s) or shell. Then fill the bowl(s) or shell with an absorbent material such as burlap, blankets, etc. Finally, cover the entire fountain with a Henri Fountain Cover. Should condensation droplets form on the inside of the cover, they will be absorbed by the material.

By following these simple and sensible precautions during the winter season, you will protect your fountain for years of beauty and enjoyment!